BIOLOGICAL / RADIOLOGICAL AGENT "WET DECON"

IDDS LINE SET UP

- 1. Remove IDDS and place on the ground in front of you.
- 2. Open IDDS and conduct canister exchange if wearing PAPR or SCBA.
- 4. Remove plastic bags and set up in front of you.
- 5. Remove clean side wipes, open and drop contents across the hot line.
- 6. Remove all recoverable items and place into recoverable bag, secure and tag.
- 7. Remove each others non-recoverable equipment place in non-recoverable bag.

GROSS DECONTAMINATION – BUDDY SYSTEM

- 1. Set up 12X12 inner bag, add contents of the HTH / surfactant package, add water, close decon-media bag and swirl to mix for 30 seconds.
- 2. Place cut-out tools and shammy into decon-media bag.
- 3. Discard IDDS bag into non-recoverable waste bag.
- 4. Using the shammy, conduct buddy gross decon, wiping from head to toe.

PROTECTIVE SUIT CUT OUT - BUDDY SYSTEM

- 1. Cut hood strap; wrist straps; waist straps; legs straps; boot laces (remove boots) *decon hands and tools between each cut*.
- 2. Cut buddy's hood to the nape of neck decon hands and tools.
- Continue to cut down the back through the suspenders down the right/left leg decon hands and tools.
- 4. Cut down from the buttocks down the left/right leg decon hands and tools.
- 5. Remove garment over the arms and over the hands, lay garment on the ground, rolling garment inward onto itself *decon hands*.
- 6. Step on Buddies suit, have buddy walk out decon hands and tools.
- 7. Pick up suit, rolling garment inward and discard decon hands
- 8. Buddy #2 repeats steps 1 7 on Buddy #1.
- 9. Buddy#1 cuts the front of either the right/left Sealskin sock *decon hands* and tools.
- 10. Buddy#2 repeats step 9
- 11. Step out of socks and across the hot line using the buddy system.
- 12. Dispose of decon-media bag and perform a self glove removal into the non-recoverable waste bag.
- 13. Hold breath, remove mask and place in the non-recoverable waste bag.
- 14. Open clean-side wipe bag, wipe face and hands with Chlorine wipe.

CHEMICAL AGENT "DRY DECON"

IDDS LINE SET UP

- 1. Remove IDDS and place on the ground in front of you.
- 2. Open IDDS conduct canister exchange if wearing PAPR or SCBA.
- 4. Remove plastic bags and set up in front of you.
- 5. Remove clean side wipes, open and drop contents across the hot line.
- 6. Remove all recoverable items and place into recoverable bag, secure and tag.
- 7. Remove each others non-recoverable equipment place in non-recoverable bag.

GROSS DECONTAMINATION – BUDDY SYSTEM

1. With a NanosweepTM, conduct gross buddy decon, head to toe, discard mitt in the plastic bag.

PROTECTIVE SUIT CUT OUT – BUDDY SYSTEM

- 1. Cut hood strap; wrist straps; waist straps; legs straps; boot laces (remove boots) *SPRAY tool*.
- 2. Cut buddy's hood to the nape of neck *SPRAY tools*.
- 3. Continue to cut down the back through the suspenders down the right/left leg *SPRAY tools*.
- 4. Cut down from the buttocks down the left/right leg *SPRAY tools*.
- 5. Remove garment over the arms and over the hands, lay garment on the ground, rolling garment inward onto itself *SPRAY*.
- 6. Step on Buddies suit, have buddy walk out SPRAY tools.
- 7. Pick up suit, rolling garment inward and discard decon hands
- 8. Buddy #2 repeats steps 1 7 on Buddy #1.
- 9. Buddy#1 cuts the front of either the right/left Sealskin sock *SPRAY tools*.
- 10. <u>Buddy#2 repeats step 9</u>
- 11. Step out of socks and across the hot line using the buddy system.
- 12. Dispose of decon-media bag and perform a self glove removal into the non-recoverable waste bag.
- 13. Hold breath, remove mask and place in the non-recoverable waste bag.
- 14. Open clean-side wipe bag, wipe face and hands with Chlorine wipe.